

# Air 3 True Wireless Earbuds

Model #: 14321, 14281, 14591, WL14681



## PAIRING AND POWERING OFF EARBUDS:

### Notes for Pairing:

- Keep the distance between your smartphone and the Earbuds within 3 ft (for pairing only).
- The Earbuds must be powered ON in order to pair.
- Before attempting to pair, make sure that your smartphone or tablet's Bluetooth function is enabled under Settings. Specific pairing procedures will be different depending on different brands and models. For detailed information on pairing, please refer to your device's user manual.

**STEP 1:** Take Earbuds out of charging case and they will power on automatically. If Earbuds are already out of charging case, then gently press and hold the multifunction buttons on each earbud for 8 seconds. You will see the LED flash white and blue on each side, indicating that the power is ON. Your Earbuds are now in Pairing Mode.

**STEP 2:** Open your smart device's Settings menu and activate Bluetooth pairing. Your smart device (tablet, smartphone, etc.) will perform a search for local Bluetooth enabled products; after a few seconds you will see 'Air3' appear on the list.

**STEP 3:** Select 'Air3' from the list. Once selected, your Earbuds are ready for use.\*

\*You may wish to only use one earbud (single mode) instead of using the pair together (dual mode). When this is the case, simply turn on the earbud you wish to use and follow the same steps while keeping the other earbud turned off. You will have the same general functionality.

### AUTO-PAIRING:

Once you have successfully paired your earbuds to a Bluetooth-enabled device, that device will remember and recognize your earbuds for automatic re-pairing. This means that the next time you wish to use your earbuds with that same smart device, pairing will happen automatically and without the need for you to revisit your device's Bluetooth display screen.

### POWER OFF EACH INDIVIDUAL EARBUD:

Press and hold the Multifunction Button on either earbud for 5 seconds, both Earbuds will power off.

**Note:** If your device's Bluetooth version is below version 2.1, you may need to enter the password '0000'.

**READING THE LED INDICATOR:**

	<b>LED INDICATION</b>	<b>MEANING</b>
<b>AIR3</b>	LED flashes white/blue after holding multi-fn button for 5 seconds.	The earbuds have just powered on and are in pairing mode.
	LED turns off after holding multi-fn button for 8 seconds.	The earbuds are powering off.
	LED flashes white once every 5 seconds.	The unit has low power and should be recharged.
	LED glows solid white.	The earbuds and/or case are charging.
<b>CHARGING CASE</b>	LED does not display any colors/light.	The earbuds and case are fully charged.
	1 of 2 blue LEDs are illuminated.	The unit is operating with < 50% battery life.
	Both blue LEDs are illuminated.	The unit is operating with 75-100% battery life.

**FUNCTIONS & ACTIONS:**

	<b>FUNCTION</b>	<b>ACTION</b>
<b>BLUETOOTH CALLING</b>	Caller ID	When receiving an incoming call, the number will be read aloud.
	Answer a call	Gently single-click left or right earbud while receiving a call.
	End a call	Gently single-click left or right earbud during a call.
	Reject/ignore a call	Gently double-click left or right earbud while receiving a call.
<b>MUSIC &amp; AUDIO</b>	Play or pause	Gently single-click left or right earbud (once paired to a device).
	Previous/next track	Gently double-click left or right earbud.
	Volume +/-	Long touch left or right earbud for 1 second.
	Playlist controls	Use your paired device (such as a smartphone or tablet) to control.
<b>GENERAL</b>	Activate Siri/Voice Assistant	Gently triple-click left or right earbud.
	Turn on/off	Long touch left or right earbud for 8 seconds.

## **CHARGING YOUR EARBUDS & CASE:**

- 1) Insert the earbuds into their corresponding charging chamber in the case.
- 2) Magnetic charging connectors should lock earbuds securely into charging chambers. Close the case.
- 3) Insert the included Type-C USB charging cable into the back of the charging case and connect to a power source (such as a power bank, AC wall adapter, etc.)
- 4) You will see the earbuds flash white to indicate that automatic charging has begun. The case's interior LED charge indicator will glow white while charging.
- 5) When they have finished charging, earbud LEDs will turn off to indicate they are fully charged.

## **COMMON PROBLEMS AND SOLUTIONS:**

### **Smart device cannot find Bluetooth earbuds**

Check that earbuds power is switched on. If Air3 earbuds have not been found after switching power on, restart both earbuds and smart device.

### **Problems with Bluetooth earbuds while in use**

Re-connect to smart device after turning off and restarting earbuds. Check charge status of earbuds by placing in charge case until LED indicator is on. Then remove and re-connect via Bluetooth to device.

### **TWS Earbuds frequently disconnect or make noise when connected**

The Bluetooth earbud's power status is probably low and needs to be recharged. There may also be an obstruction between smart device and Bluetooth earbuds, or the distance may be beyond the signal range.

### **Cannot switch from single earbud connection to dual earbud connection**

Turn off single earbud smart device Bluetooth connection. Turn back on, dual earbuds lights will flash white and blue. Double click one of the earbuds and dual earbuds will be paired.